




# QUICK-SWITCH™ NORMALLING SWITCH SETTINGS




FN & IG




HN & IG




NN & IG




FN & GB




HN & GB  
Factory Settings




NN & GB



FN & GVS



HN & GVS



NN & GVS

## SWITCH SETTINGS

Switch positions shown from rear view of the unit

### Top Two Switches (Grounds)

IG = ISOLATED GROUNDS

GB = GROUNDS BUSSED

GVS = GROUNDS VERTICALLY STRAPPED

### Bottom Two Switches (Normalling)

FN = FULL-NORMALLED

HN = HALF-NORMALLED (ROW 1 TO ROW 2)

NN = NON-NORMALLED

### \*\*\*\*\*Caution\*\*\*\*\*

Slide switches left or right to the appropriate position

DO NOT PULL SWITCHES OFF

Irreplaceable damage will occur